




**POWERWAVE**  
ACCESSORIES

# AC ADAPTER

INSTRUCTIONS



## Contents

PRODUCT OVERVIEW .....	2
AC ADAPTER SPECIFICATIONS .....	2
CONTENTS .....	2
PRODUCT CARE AND SAFETY .....	2



**POWERWAVE**  
ACCESSORIES

# AC ADAPTER

## INSTRUCTIONS

### Product Overview

The Powerwave Switch AC Adapter supports all your Nintendo Switch™ charging needs. Compatible with Nintendo Switch 2 consoles, docks and charging stations. Recharge your battery even while you play!

### AC Adapter Specifications

Input Voltage Range:	100V – 240V 1.5A
Input Frequency:	50/60Hz
Output Voltage:	5.0 – 20.0Vdc
Output Current:	3.0 – 3.25A
Output Rated Load:	+5.0V: 0 – 3.0A +9.0V: 0 – 3.0A +12.0V: 0 – 3.0A +15.0V: 0 – 3.0A +20.0V: 0 – 3.25A

### Contents

1x AC Adapter

### Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.
- Connect the AC Adapter to the correct voltage.
- Do not touch the AC Adapter connectors with your fingers or metal objects.
- Do not touch the AC Adapter or connected devices while charging during a thunderstorm.