



CAR CHARGER

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
AC ADAPTER SPECIFICATIONS:	2
CONTENTS	2
PRODUCT CARE AND SAFFTY	2



POWERWAVE

CAR CHARGER

INSTRUCTIONS

Product Overview

Keep your Switch™ or Switch 2 console charged while traveling with the Powerwave Car Charger. Plugging directly into your car, this 15V/2A (30W) USB-C charger will keep your console ready for action on long road trips.

Car Charger Specifications

Input Voltage Range:	DC 12V — 24V
Output Voltage:	5.0 — 20.0Vdc
Output Current:	1.5 — 3.0A
Output Rated Load:	+5.0V: 0 - 3.0A +9.0V: 0 - 3.0A +12.0V: 0 - 2.5A +15.0V: 0 - 2.0A +20.0V: 0 - 1.5A

Contents

1x Car Charger

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.

- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt buildup. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.
- Connect the AC Adapter to the correct voltage.
- Do not touch the AC Adapter connectors with your fingers or metal objects.
- Do not touch the AC Adapter or connected devices while charging during a thunderstorm.