



**POWERWAVE**  
A C C E S S O R I E S

# CHARGING GRIP

INSTRUCTIONS



## Contents

PRODUCT OVERVIEW .....	2
LAYOUT .....	2
OPERATING INSTRUCTIONS .....	2
CONTENTS .....	3
PRODUCT CARE AND SAFETY .....	3




# CHARGING GRIP

## INSTRUCTIONS

### Product Overview

Upgrade your controller experience with the Powerwave Charging Grip. Featuring a pivot mechanism, the centre piece raises to provide easy access to the magnetic connection points. With the built-in USB-C power pass-through this grip allows you to charge your controllers while playing, ensuring uninterrupted gaming whilst the ergonomic design offers a comfortable hold, perfect for extended sessions.

### Layout



### Operating Instructions

- Lift the middle of the charging grip to allow access to the magnetic charging ports
- Connect controllers to the charging ports and lower the middle section to its original position
- When charging your controllers the charging indicator lights will illuminate red, and will display green when fully charged



# CHARGING GRIP

## INSTRUCTIONS

### Contents

- Charging Grip
- 2M USB-A to C Charging Cable

### Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.