

# HDMI 4K 2.0 4X PORT SWITCH

INSTRUCTIONS



### Contents

PRODUCT OVERVIEW	. 2
PRODUCT LAYOUT	. 2
INSTRUCTIONS FOR USE	. 3
PRODUCT CARE AND SAFETY	. 3
PRODUCT SPECIFICATIONS	. 4



### POWERWAVE


## HDMI 4K 2.0 4X PORT SWITCH


INSTRUCTIONS

#### **Product Overview**

Connect up to four HDMI sources to one HDMI display port with the Powerwave HDMI 4K 2.0 4 Port Switch. Easily switch between up to four gaming consoles, media players or other HDMI devices. Easy to setup, just plug in your devices & connect the power cable and you're ready to go. Switch to each device with a simple press of a button, no need to unplug devices when they're not in use. The Powerwave HDMI 4K 2.0 4 Port Switch displays content in high definition supporting 4K at 60hz, HDCP, HDR, Dolby Vision and transparent transmission of Dolby Digital, DTS, 5.1 Surround Sound Audio.

### **Product Layout**







### POWERWAVE

## HDMI 4K 2.0 4X PORT SWITCH

#### INSTRUCTIONS

### Instructions For Use

- Place the HDMI Switch on a dry, flat surface.
- Insert the 5V circular end of the power cable supplied into the Power Input of the HDMI Switch and the USB-A
  end into an available USB port or 5V/1A AC adapter.
- Insert one end of a HDMI cable (not included) in a HDMI port of the desired output display device and the other
  end into the Output port on the HDMI Switch.
- Use the HDMI Input Ports (1-4) to connect your devices to the HDMI Switch.
- Turn the Power Switch on and use the Input Indicator Light to identify the HDMI port that is currently active.
- To display the HDMI input of your choice use the Select Button.

### **Product Care and Safety**

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- Please use the included 5V / 1A cable.
- For indoor use only.
- · Keep away from hot surfaces and naked flames.
- Do not expose this product to any liquids.
- Do not install or place in a bookcase, built-in cabinet or in another confined space. Ensure the product is well ventilated.
- Unplug from power during lightning storms or when unused for long periods of time
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.

- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- · Protect the power cord from being pinched.
- Clean with a soft, dry cloth to prevent dirt buildup. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.



### POWERWAVE

## HDMI 4K 2.0 4X PORT SWITCH

INSTRUCTIONS

### **Product Specifications**

Specifications	
Input Video Signal	0.5 - 1.0 Volts P-P
Input DDC Signal	5 Volts P-P (TTL)
Maximum Single Link Range	3840*2160@60Hz
HDMI Compliance	HDMI 2.0 HDCP2.2
HDMI resolution	30/50/60Hz/2160,1080
Max band rate	18Gbps/600MHz
Size	W179 x D67 x H22 (mm)
Net Weight	250G
Operating Temperature	0°C to 60°C
Operating Humidity	10% to 85 % RH
Storage Temperature	-10°C to 70°C
Storage Humidity	5% to 90 % RH
Power Requirement	3.5W/DC 5V 1A