



**POWERWAVE**  
ACCESSORIES  
INSTRUCTIONS

**EVA  
CARRY CASE**



**Contents**

PRODUCT OVERVIEW ..... 2

CONTENTS ..... 2

PRODUCT CARE AND SAFETY ..... 2



# EVA CARRY CASE

## INSTRUCTIONS

### Product Overview

Protect your Nintendo Switch 2 Console with the Powerwave EVA Carry Case. The durable EVA material protects your console from everyday wear and tear while on the go.

Stay organised with a cartridge sleeve providing storage for up to 10 game cartridges. The internal mesh pocket holds additional accessories during transit.

### Contents

1x EVA Carry Case

### Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.