




INSTRUCTIONS

# 2M USB-C LED CHARGING CABLE WITH ADJUSTABLE HEAD AND USB-A ADAPTER



# Contents

PRODUCT OVERVIEW	. 2
CONTENTS	. 2
PRODUCT CARE AND SAFETY	2



## POWERWAVE

# 2M USB-C LED CHARGING CABLE WITH ADJUSTABLE HEAD AND USB-A ADAPTER

INSTRUCTIONS

## Product Overview

Charge your device with the Powerwave 2M USB-C LED Charging Cable with Adjustable head. The swivelling head ensures that your devices can connect even at tight angles while the LED indicators subtly displays when devices are connected. Plug the USB-A adapter into the dock to easily add the convenience of a USB-C port. The 60W cable allows you to charge whilst playing and supports data transfer.

### Contents

1x 2M USB-C LED Charging Cable with Adjustable Head 1x USB-C to USB-A Adapter

## **Product Care and Safety**

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- · For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.