



POWERWAVE
ACCESSORIES

MULTIFUNCTIONAL GRIP

INSTRUCTIONS



Contents

PRODUCT OVERVIEW.....	2
LAYOUT.....	2
OPERATING INSTRUCTIONS.....	3
CONTENTS.....	3
PRODUCT CARE AND SAFETY.....	3



MULTIFUNCTIONAL GRIP

INSTRUCTIONS

Product Overview

Adjust your controller layout with the Powerwave Multifunctional Grip. Play using either single or dual layout to suit your preference. The Dual controller mount includes power pass-through to charge whilst playing and the ergonomic design offers a comfortable hold in both layouts, perfect for all gaming scenarios.

Layout





MULTIFUNCTIONAL GRIP

INSTRUCTIONS

Operating Instructions

Single Controller Layout:

- Insert controller into the Single Controller Mount
- Slide the Single Controller Mount and controller onto the Grip, ensuring that it clicks into place
- To remove the Single Controller Mount press the button on the back of the grip and slide upwards

Dual Controller Layout:

- Attach controllers to the magnetic connectors of the Dual Controller Mount
- Slide the Dual Controller Mount and controllers onto the Grip, ensuring that it clicks into place
- To remove the Dual Controller Mount press the button on the back of the grip and slide upwards
- The Dual Controller Mount also supports charging via USB-C port

Contents

- 1x Grip
- 1x Dual Controller Mount
- 1x Single Controller Mount

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.