


PRO THUMB GRIPS

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	. 2
THUMBSTICKS	. 2
INSTALLATION INSTRUCTIONS	. 2
CONTENTS	. 2
PRODUCT CARE AND SAFETY	. 3





PRO THUMB GRIPS

INSTRUCTIONS

Product Overview

Improve your control with the Powerwave Pro Thumb Grips. The four stick options each provide different heights and movement radius to suit your preference and increase accuracy and reaction speed while gaming. These Thumb Grips also serve to protect your controllers Joysticks from everyday wear and tear.

Thumbsticks



Installation Instructions

- 1. Lift the edge of the Thumb Grips
- 2. Place the Thumb Grips over the joystick and fold the edge down
- 3. Adjust the edge to ensure it fully covers the joystick

Contents

- 1x Original Pair
- 1x Focus Pair
- 1x Apex Pair
- 1x Ascend Pair





PRO THUMB GRIPS

INSTRUCTIONS

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.