




POWERWAVE
ACCESSORIES

PROTECTIVE CASE WITH GRIPS

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
OPERATING INSTRUCTIONS	2
CONTENTS	2
PRODUCT CARE AND SAFETY	2



POWERWAVE
ACCESSORIES

PROTECTIVE CASE WITH GRIPS

INSTRUCTIONS

Product Overview

Protect your console with the Powerwave Protective Case with Grips. The ergonomic back grips improve comfort in hand and the hard shell protects from drops, scratches and bumps whilst still allowing access to all buttons and ports. The slim design also allows for the console to be docked without needing to be removed from the case.

Operating Instructions

- Align the top of your console with the top of the Protective Case, the triggers should fit into the trigger gaps
- Press the bottom of the console into the case, ensuring an even fit across the console

Contents

- 1x Protective Case with Back Grips

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.