



POWERWAVE
A C C E S S O R I E S

QUAD CHARGING STAND

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
LAYOUT	2
OPERATING INSTRUCTIONS	2
CONTENTS	3
PRODUCT CARE AND SAFETY	3



QUAD CHARGING STAND

INSTRUCTIONS

Product Overview

Charge up to four controllers simultaneously with the Powerwave Quad Charging Stand. Powered by USB the LED indicators on top of the tower allow you to easily monitor the charging status of your controllers.

Layout



Operating Instructions

- Connect your Charging Stand to power using the included USB-A Cable.
- Connect your Joy-Cons to the Charging Stand, ensuring that the left and right Joy-Cons are on the correct side, indicated by the “-” and “+” symbols on the Stand.
- Your Joy-Cons will now be charging, charging status can be seen on the top of the stand. The indicator lights will display red when charging and green when fully charged.



QUAD CHARGING STAND

INSTRUCTIONS

Contents

- 1x Quad Charging Stand

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.