



POWERWAVE
ACCESSORIES

STARTER PACK

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
CONTENTS	2
PRODUCT CARE AND SAFETY	2



STARTER PACK

INSTRUCTIONS

Product Overview

The Powerwave Starter Pack includes everything you need to keep your console safe. Includes -

EVA Case:

Protect your Nintendo Switch™ 2 Console with the Powerwave EVA Carry Case. The durable EVA material protects your console from everyday wear and tear while on the go and the internal mesh pocket holds additional accessories during transit.

Screen Protector:

Shield your Switch™ 2 console screen from scratches, smudges and bumps without sacrificing clarity with this screen protector.

Cartridge Case:

Safely store your 4 favourite Nintendo Switch™ or Switch 2 games in this cartridge case.

Contents

- 1x EVA Case
- 1x Screen Protector
- 1x Cartridge Case
- 2x Alcohol Wipes (1x Wet & 1x Dry)
- 1x Cleaning Cloth

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.