



**POWERWAVE**  
A C C E S S O R I E S

# TEMPERED GLASS SCREEN PROTECTOR

INSTRUCTIONS



## Contents

PRODUCT OVERVIEW .....	2
INSTALLATION INSTRUCTIONS.....	2
CONTENTS .....	2
PRODUCT CARE AND SAFETY .....	2



# TEMPERED GLASS SCREEN PROTECTOR

## INSTRUCTIONS

### Product Overview

Shield your Switch™ 2 console screen from scratches, smudges and bumps without sacrificing clarity with the Powerwave Tempered Glass Screen Protector.

### Installation Instructions

1. Clean surface with wet wipe, follow with dry wipe, finish with the cleaning cloth
2. Remove protective plastic film from screen protector
3. Align correctly over console screen and push down
4. Apply pressure over entire screen to secure in place. Smooth carefully with cloth to remove any remaining air bubbles

### Contents

- 1x Tempered Glass Screen Protector
- 1x Cleaning Cloth
- 2x Alcohol Wipes (1x Wet & 1x Dry)

### Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.