



DUAL CHARGING DOCK



Contents

PRODUCT OVERVIEW	2
LAYOUT	2
CONTENTS	3
OPERATING INSTRUCTIONS	3
PRODUCT CARE AND SAFETY	3




DUAL CHARGING DOCK

INSTRUCTIONS

Product Overview

Experience versatility with the Powerwave Dual Grip Charging Dock. Seamlessly charge up to four controllers at once by connecting them to the dock, or detach the grips for individual charging convenience and enhanced gameplay comfort. Built-in LED indicators provide instant updates on battery levels, ensuring you're always ready to play.

Layout





DUAL CHARGING DOCK

INSTRUCTIONS

Operating Instructions

- Connect your Charging Base to power using the included USB-C Cable.
- Dock your Charging Grips to the base.
- Connect your Joy-Cons to the Charging Grips using the magnetic charging ports.
- Your Joy-Cons will now be charging, charging status can be seen on the top of each grip.
The indicator lights will display red when charging and green when fully charged.

Contents

1x Charging Dock
2x Charging Grips
1x USB-C Charging Cable

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.