



POWERWAVE
A C C E S S O R I E S

SLIM SOFT TRAVEL CASE

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
CONTENTS	2
PRODUCT CARE AND SAFETY	2



SLIM SOFT TRAVEL CASE

INSTRUCTIONS

Product Overview

Protect your Nintendo Switch™ 2 console in style with the Powerwave Slim Soft Travel Case. The lightweight and durable design protects against scratches, dirt and bumps and the soft fabric interior ensures your console remains safe when taking in or out of the case.

Contents

- 1x Slim Soft Travel Case

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.