

TEMPERED GLASS SCREEN PROTECTOR

INSTRUCTIONS



Contents

PRODUCT OVERVIEW	2
INSTALLATION INSTRUCTIONS	2
CONTENTS	2
PRODUCT CARE AND SAFETY	2



POWERWAVE

TEMPERED GLASS SCREEN PROTECTOR

INSTRUCTIONS

Product Overview

Protect your Xbox ROG Ally or Ally X from scratches, smudges and bumps without sacrificing clarity with the Powerwave Tempered Glass Screen Protector.

Installation Instructions

- 1. Clean surface with wet wipe and cleaning cloth.
- 2. Use the dust sticker to remove any stubborn pieces of dust.
- 3. Remove protective plastic film.
- 4. Align correctly over screen and push down.
- 5. Apply pressure over the entire screen to secure in place. Smooth carefully with cloth to remove any remaining.

Contents

- Tempered Glass Screen Protector
- Cleaning Cloth
- Wet Wipe
- Dust Removing Sticker

Product Care and Safety

- Keep your user manual for future reference.
- Use this device solely for its intended purposes.
- · For indoor use only.
- Keep away from hot surfaces and naked flames and liquids.
- When not in use, store in a cool, dry environment away from direct sunlight.
- Do not apply force or put heavy objects onto the product.
- If the product is damaged, broken or immersed in water, stop use immediately.
- Do not attempt to repair, modify or disassemble the product.
- Clean with a soft, dry cloth to prevent dirt build-up. Do not use chemical solvents, detergents or alcohol.
- Keep out of reach of small children.